




RMO-W208MG/RMO-W209MG

20 升 燒烤微波爐

20L Grill Microwave Oven



僅適用於家庭使用
For household use only

使用說明書 OPERATION MANUAL

在使用本產品前，請仔細閱讀本說明書，並妥善保存本說明書以備用戶日後查詢。

Please read the operation manual carefully before using and well keep it in a safe place for future reference.

本說明書中的圖示可能有與實物不同的地方，僅供參考。

Some figures in this manual may not match with the real object, just for reference only.

非常感謝您選購樂信牌燒烤微波爐，在使用前請先詳細閱讀本說明書，並保存以備日後參考。

目錄

1. 安裝注意事項
2. 安全注意事項
3. 器皿注意事項
4. 清潔及儲存
5. 產品規格
6. 產品說明
7. 使用方法
8. 特別聲明
9. 售後服務

使用本燒烤微波爐時，必須遵守下列安全注意事項：

警告！不當使用會導傷亡及機件損毀

1. 安裝注意事項

為了防止火災、灼傷和觸電，使用前請先了解以下事項

1. 本產品屬於高耗電量電器，請使用獨立電源插座，不應與其他電器共用一個電源插座。確保當地的電壓與本產品上所標明的額定電壓相符。
 2. 為防止觸電，必須確保微波爐接地良好。
 3. 本產品的淨重約為11公斤，用戶應將本產品放置於有足夠承托力的水平面上使用。
 4. 使用時需有足夠的通風。本產品乃屬座檯式型號，**切勿**安裝於櫃內，避免堵塞微波爐的通風排氣孔，以免造成過熱。切勿在微波爐頂部放置任何物件。
 5. 微波爐頂部必須與牆壁保持至少20厘米的距離；爐的兩旁應與牆壁保持至少5厘米的距離；爐背與牆壁保持至少10厘米的距離；產品與地面亦須保持至少85厘米的距離。用戶亦可利用爐背的距阻限定有關距離。請勿擅自拆去爐腳。
 6. 切勿將本產品應放置於低耐溫的物料上使用，如塑膠檯布、棉檯布等。
 7. 應將本產品放在通風及乾爽的地方，並須遠離腐蝕性氣體、火源、高溫、蒸氣、潮濕、油煙或接觸到易燃物的環境中使用。
 8. 如室內溫度過高，建議不要使用微波爐。
 9. 安裝位置應遠離電視、收音機或天線以免造成的干擾。否則可能會引起噪音。
- 警告：**如爐門損壞，在未得到合資格受訓人員維修前，切勿使用。

2. 安全注意事項

2.1 首次使用

1. 將微波爐內的包裝物料全部取出。如微波爐的外殼上附有保護膜，請將保護膜撕掉後再使用。（注意：切勿拆除爐內右壁上的導波管蓋。）
2. 徹底檢查微波爐及配件有否損壞及裂痕，如門鎖、爐門及玻璃轉盤等位置。如有損壞，請不要安裝或使用本產品。
3. 首次使用燒烤功能可能會出現冒煙或輕微燒焦味，此為正常現象，並非產品故障。如欲避免影響烹調可於放食物前，以燒烤功能加熱空爐20分鐘，打開爐門冷卻十分鐘後才使用。
4. 於生產過程可能有保護油殘留機體內腔，並可能有異味或輕煙釋出，這仍屬正常現象，使用數次後情況將會有所改善。使用時保持窗門通風良好。

2.2 預防微波爐內腔起火

1. 切勿過度加熱食物。
2. 移除食物及其包裝上的所有金屬封口、扎線圈等，因金屬表面形成的電弧可能會起火。
3. 加熱塑膠或紙品盛載的食物時，請確保它們是適用於微波爐烹調，由於它們屬易燃性質，請時刻留意加熱情況。
4. 切勿用微波加熱食用油或油炸食物，因為油溫會變得很高而難以控制。
5. 如欲烹調爆谷，必須使用微波爐適用的爆谷專用袋子。
6. 經常清潔產品內腔，特別是爐門、爐門與內腔間的縫隙、右壁上的導波管蓋（導波管蓋只可用乾布拭擦），以免油脂積聚。因積存的油污，有可能引致微波爐表面變質而造成黑煙，甚至起火，影響產品的使用壽命及其他危險。
7. 如烹調過程中冒煙或起火，請保持爐門緊閉以壓制任何火焰，否則遇上空氣會加大火勢。在安全情況下，用戶應立即停止操作，並拔掉電源插頭或關掉屋內電源總開關。

2.3 預防微波外洩

為防止微波外洩的危險，請注意以下預防事項：

1. **警告！**切勿損壞爐門的安全鎖系統。如發現爐門不能緊閉、爐門變形或爐門的組件損壞（如門栓），應立即停止使用，並聯絡信興電器服務中心有限公司進行維修後，才可再使用。
2. 操作時，請勿置入任何物品，特別是金屬物體（如速食食品之鋁箔包裝等）。

3. 使用前，必須放入轉盤旋轉架及玻璃轉盤。
4. 切勿空機使用微波功能。使用時，爐內應放有可吸收能量的物質(如食物或水)。避免微波能量在爐內不停反射，影響微波爐的性能。若微波爐在沒有放置食物的情況下錯誤被啟動，應立即停止操作。
5. 切勿使用微波爐加熱化學劑或其他非食物製品，亦不可用含有腐蝕性化學劑的製品清洗本產品。
6. **警告！**維修工作或涉及拆開爐身及拆除波導管蓋工序，有可能導致微波洩漏，屬非常危險的情況，必須由合資格人士進行。如需檢查或維修，請聯絡信興電器服務中心有限公司。

2.4 食物注意事項

1. 加熱嬰兒食品時，在餵食前須將食物加以攪拌及測試溫度，以確保熱力分佈均勻，從而避免燙傷或灼傷嬰兒。
2. 切勿加熱生雞蛋、烩蛋或連蛋殼蛋，因壓力會使雞蛋爆裂。蛋黃、蛋白也須用牙簽刺穿。另外，切勿馬上取出已煮好的湯圓或荷包蛋，會造成食物內的液體沸濺而造成燙傷。用戶應先打開爐門，擱置一會後再取出食用。
3. 先將表面沒有細孔的食物(如蛋、栗子、馬鈴薯、香腸等帶皮食物)去皮，或在表皮上開一些裂縫或用叉子穿幾個細孔；否則，食物有可能受熱膨脹後發生爆濺。嚴格遵照食物包裝上的標籤指示，使用適當的方法烹調。
4. 烹飪少量食物時，小心觀察食物情況，防止過熱起火。
5. 如需使用保鮮紙遮蓋食物，請使用微波爐專用的保鮮紙，並請將保鮮紙一角摺起使之通氣。烹調後，小心將保鮮紙拆開，以免被蒸氣灼傷。
6. 加熱飲品後，熱力有可能被鎖於液體內而出現延遲沸騰爆濺。因此，在烹調時及移動容器時必須格外小心。
7. 烹調的效果或會因喜好的生熟程度、開始時溫度、使用地區海拔高度、份量、大小、食物形狀和盛載器皿有所影響。用戶可因應經驗調節烹調時間。

2.5 操作注意事項

1. 切勿於爐腔內儲存任何物品(如紙品、廚房器具及食物等。)
2. 必須使用原廠的玻璃轉盤及轉盤旋轉架，切勿自行更換其他非生產商授權的零件或配件，以免造成危險及令維修保養告無效。
3. 切勿加熱再生紙製品，因其含有容易引起火花和易燃雜質。
4. 切勿敲打控制面板，以免破壞控制器。
5. 如非說明書所指定，不可直接在玻璃轉盤上烹煮食物。(食物必須放入適合的烹調器皿中。)
6. 確保容器與產品爐壁保持一定距離，並置於玻璃轉盤範圍內，以免影響轉盤轉動及加熱效果。
7. 切勿將易燃物放在爐內或爐頂，以免導致起火。
8. 切勿在開啟的爐門上放置物件。
9. 應使用微波爐專用測肉溫度計檢查牛肉及雞肉烹調結果。切勿把水銀溫度計放入微波爐中加熱或測量，以免引起火災或造成損壞。
10. 切勿使用外置計時器或遙控系統來操作本產品。
11. 應使用微波及燒烤爐專用的厚手套放入、翻轉或取出食物，以免被高溫燙傷。
12. 運作時或使用後，外殼、爐內及可觸及部件溫度或會變得灼熱切勿觸摸。小孩必須與產品保持距離，或於成人監督或指導下方可使用。
13. 使用時，少量蒸氣會於微波爐內外聚積，形成水滴。此屬正常現象，用戶可用軟布擦淨。此情況於濕度高且正常使用下亦會出現，微波爐仍可安全使用，待產品冷卻後蒸氣便會自動消散。
14. 開啟微波爐門時，請注意力度並留意機內的食物會否濺出或弄翻，以免造成危險。特別於烹煮熱湯或飲品等流質食物時，請格外小心。
15. 切勿將本產品用於烹飪以外的其他用途。(如果本產品用於烹飪以外，則可能會發生故障。)
16. 微波爐只適用於加熱食物和飲料。若用於烘乾食物或衣服，以及加熱取暖墊、治療工具(如：小麥袋等)、拖鞋、海綿、抹布或報紙等，可能會導致產品固障、起火或火災。
17. 為防止玻璃轉盤受損壞，請遵守下列事項：
 - a. 用水清洗轉盤時，應先待其冷卻。
 - b. 切勿放置滾熱的食品或灼熱的容器於冰冷的玻璃轉盤上。
 - c. 切勿放置冰冷的食品或冰冷的容器於灼熱的玻璃轉盤上。
 - d. 玻璃轉盤的最大的負載重量不能超過4.5公斤。
18. 切勿將機身、電源線或插頭浸入水中或用水淋洗，以免影響電器的安全性能及防止造成觸電的危險。

19. 小心使用電源線，不可在電源線上放重物或夾住電源線；不可改裝電源線；切勿用力拉扯或扭曲電線，在拔出或插入插頭時，要用手握穩插頭本身。切勿將電源線懸掛在桌子、櫥櫃的邊緣或令其接觸發熱的表面。
20. 使用後或長期不使用時，應將插頭從插座拔出，以免因絕緣老化而發生漏電及觸電危險。切勿使用濕手接觸、插入或拔出插頭，以免觸電。
21. 移動、檢查或清潔微波爐前，應先拔掉電源線插頭，待微波爐冷卻後再進行。
22. 本產品只可作家庭使用，切勿在室外使用或用作說明書建議以外的其他用途。如不當使用此微波爐，或作為(半)商業用途，維修保養將告無效，本公司將不會承擔任何損壞的維修責任及賠償。
23. 切勿讓嬰兒靠近。若有孩童在旁，須加倍小心使用及看管小孩，以確保他們不會把此產品當作玩具。切勿讓小孩單獨使用或進行保養，亦切勿將本產品及其電源線放於小孩能觸及的地方。
24. 本產品可供年齡在8歲或以上的兒童及體質、感覺或智力有障礙人士或缺乏經驗和相關知識的人士使用，但他們必須接受負責安全人士的監督或指導如何安全地使用產品和理解所涉及的危險。
25. 本產品是家用或在類似環境使用，如：商店內部、辦事處以及其他工作環境的員工廚房區域或類型的環境。切勿於戶外使用。
26. 經常檢查電源線、插頭、爐門及門鎖是否有破損，或曾經有跌落情況，為避免危險應停止使用，並聯絡信興電器服務中心有限公司作檢查及維修。
27. 遵從安全守則及避免釀成意外，如需維修電器，請聯絡信興電器服務中心有限公司(地址印於本使用說明書的背頁或致電2406 5666查詢)，並確保在檢查或維修時出示保修登記卡及收據。

3. 器皿注意事項

1. 檢查所使用的器皿是否適合微波爐使用。
2. 所有金屬物件、帶有金屬或銀邊的器皿亦不適用，以免產生火花或高溫而損壞本產品，造成火災或傷害。
3. 切勿把窄頸瓶器皿或密封的食物直接放入微波爐加熱，以免引起爆炸。
4. 當食物放於塑膠物料、紙或其他可燃材料製成的容器中加熱或烹調時，應時常注意，防止起火。
5. 加熱液體時，應盡量使用寬口的容器。若要加入咖啡粉、奶粉、麥片或其他沖劑，必須先將其攪拌才放入微波爐，並於加熱後待其冷卻後才食用，以免燙傷。
6. **警告：**切勿加熱密封的液體或其他食物(如密封玻璃瓶或嬰兒用奶瓶等)，因會令其爆裂。
7. 以微波爐烹調／解凍食物，必須讓微波能量穿過容器滲透到食物中，挑選適當的器皿變得非常重要。建議使用圓形／橢圓形的碟盤，因為方形／長形的碟盤令置於角落的食物會較易過熱。

以下為不同器皿的參考資料(“✓”號為適用，“✗”為不適用)：

容器	組合烹調	燒烤	微波
一般塑膠	✗	✗	✗
微波爐專用保鮮紙	✗	✗	✓
燒烤微波爐專用玻璃	✓	✓	✓
燒烤微波爐專用陶瓷容器	✓	✓	✓
一般玻璃	✗	✗	✗
微波爐專用塑膠	✗	✗	✓
錫紙或錫紙容器	✗	✓	✗
金屬網架	✗	✓	✗
金屬容器	✗	✓	✗
紙或竹製容器	✗	✗	✗

4. 清潔及儲存

1. 定期清潔本產品以去除食物殘渣。保養不善可導致其表面損壞，並影響產品的使用壽命或導致其他危險及傷亡。
2. 清潔前，必先關掉微波爐及拔掉電源插頭，待其冷卻後才進行。
3. 切勿用水或濕布直接清洗內腔之導波管蓋(置於微波爐內腔右方)。
4. 保持微波爐內外表面及爐門玻璃窗及門縫的清潔。可用沾有中性清潔劑的軟綿布或海綿擦拭，然後用沾有清水的布抹淨。避免使用硬刷子或粗糙的潔具洗刷，以免損壞微波爐內外表面及玻璃窗的保護層。(注意：切勿讓水滲入爐縫內或通風口。)
5. 切勿使用銳利的金屬刮刀來清潔爐門玻璃，因為刮刀會刮花表面，或使玻璃碎裂。
6. 切勿使用蒸氣清洗裝置清洗本產品。
7. 經常清潔玻璃轉盤及轉盤旋轉架。用戶可先用加有中性清潔劑的溫水洗擦，再用清水沖洗及完全擦乾後，再請放回原處備用。
8. 如控制面板被弄濕，請即用乾布抹擦，切勿使用粗糙及磨損性的清潔劑及潔具來抹擦控制面板。抹擦控制面板時，將爐門打開，以免錯誤啟動本產品。
9. 切勿使用有毒或腐蝕性的清潔劑進行清潔。
10. 待微波爐完全冷卻及清洗後才能儲存，先將產品放入紙箱，然後置於乾爽的環境中。
11. 切勿將電源線纏繞在微波爐四周或壓住電源線，避免造成電源線磨損和破裂。
12. 切勿在爐面與爐門之間放置任何物品，或讓灰塵、殘餘的清潔劑積存於門縫表面。


5. 產品規格

型號	RMO-W208MG	RMO-W209MG
額定電壓	220-240伏特～ 50赫茲	
額定微波頻率	2450兆赫茲	
額定輸入功率(微波)	1150瓦	
額定輸入功率(燒烤)	700-800瓦	
額定輸出功率(微波)	700瓦	
容量	20升*	
淨重	約10.1公斤	
產品尺寸(闊x深x高)	約451 x 344 x 258毫米	
內腔尺寸(闊x深x高)	約302 x 296 x 192毫米 [#]	

* 廠方建議容量


[#] 微波爐的內腔容量是根據內腔尺寸之最大闊度、深度和高度而計算。實際存放食品的容量稍少於以上數值。

6. 產品說明



1	爐門安全鎖系統	爐門必須關閉，微波爐才能工作。如產品操作時打開爐門，烹調程式將會自動終止。
2	爐門玻璃窗	可觀察食物烹調情況。
3	轉軸	玻璃轉盤就座於軸線；轉軸下面的電機驅動轉盤旋轉。
4	轉盤旋轉架	置於內腔中央。然後，將轉盤放在旋轉架上，讓它穩定在轉軸上。
5	玻璃轉盤	用於放置盛載食物的器皿。烹調時，必須正確安裝於轉盤旋轉架上方才能轉動，使食物可均勻地受熱，達至理想的烹調效果。
6	控制面板	詳見 章節6.1控制面板指南 。
7	導波管蓋(不可拆除)	位於爐內腔右方，為了擋住微波孔，防止加熱時因食物內水分噴散，導致微波孔堵塞。
8	烤架	可直接放置食物，或盛載烤盤／耐熱碟。(不適用於微波或組合加熱功能)
9	距阻	使產品與牆身保持良好通風。

6.1 控制面板指南



功能選項的應用

轉動【火力】旋鈕設定烹調功能，共有9種設定可供選擇。

微波功能

本產品5段微波火力可供選擇，順時針方向轉動【火力】旋鈕以增加火力。火力段數如下：

	微波火力	強度	建議應用烹調 [#]
1	低火力	18%	保溫食物
2	解凍*／中低火力	36%	解凍食物
3	中火力	58%	炆食物
4	中高火力	81%	烘烤食物
5	高火力	100%	快速煮食

燒烤功能

注意：由於微波爐鋼板上塗有潤滑油，在首次使用燒烤功能時，因除去留下的潤滑油而產生輕微的煙霧和異味，這屬於正常現象。

燒烤功能適合用於烘烤薄塊的肉類(如牛扒、豬扒、香腸或雞翼等)。此功能也適合烘烤三文治及令食物表面金黃香脆。

*解凍功能

可參考下表，按不同食材及重量設定附加加熱時間

食物種類	重量(公斤)	建議解凍時間(分鐘：秒鐘)*
肉類	0.1-1	1:30-26:00
家禽	0.2-1	2:30-22:00
海鮮	0.1-0.9	1:30-14:00

組合烹調

組合烹調火力分佈如下：

組合	微波時間	燒烤時間	建議應用烹調*
組合1	30%	70%	牛排
組合2	49%	51%	肉類、燒春雞
組合3	67%	33%	家禽

*此建議應用烹調及時間只作參考，用戶可因應需要及個人喜好自行調整。

警告！當以燒烤或組合烹調食物時，由於機身變得非常灼熱，兒童必須接受負責安全人士的監督或指導才可使用。

計時器的應用

1. 轉動【時間】旋鈕設定加熱時間。
2. 設定時間範圍由1分鐘至30分鐘。

7. 使用方法

1. 確保【時間】旋鈕處於“0”(關)位置，然後接駁電源，並確保通風良好。
2. 將食物放在合適的容器中(詳見**章節3.器皿注意事項**)，然後直接放到轉盤的中間位置，關上爐門。
3. 轉動【火力】旋鈕選擇所需的功能選項。
4. 轉動【時間】旋鈕選擇所需的加熱時間，微波爐燈會亮起，轉盤開始轉動，產品開始運作。
5. 加熱完成後，【時間】旋鈕會回到“0”(關)位置並有響聲提示。微波爐燈將自動關閉，轉盤亦將停止轉動。
6. 打開爐門，小心取出食物／容器。如有需要，可先把食物閒置一會後再取出。

安全備註

1. 若用戶打算於加熱途中停止運作，請將計時器旋鈕轉動至“0”(關)位置。
2. 如煮食過程中需要更改烹調時間，直接將【時間】旋鈕轉動至新時間設定即可；如煮食過程中改變火力強度或轉換功能，直接將【火力】旋鈕轉動至所需的功能選項。
3. 當煮食的時間少於3分鐘，請將【時間】旋鈕轉動至大於10分鐘位置，然後再轉回所需要的時間設定，可令時間設定更準確。

注意！確認煮食結束後【時間】旋鈕已返回到“0”(關)位置，否則當爐門關上時，微波爐將會再次啟動。

8. 特別聲明

1. 本資料上所有內容經過核對，如有任何印刷及內容上的誤解，本公司將保留解釋權。
2. 本產品若有技術改進，會編進新版說明書中，恕不另行通知；產品外觀、顏色如有改動，則以製造商資料為準。
3. 如本資料之中英文版本有差異時，應以中文版為準。
4. 使用說明書的電子副本可通過電子郵件發送致客戶。如有需要，可致電信興電工工程有限公司：2861 2767。

9. 售後服務

1. 由購買收據日期起之一年保修期內，經信興電器服務中心有限公司之服務人員證實產品故障屬正常使用情況下發生者，本公司將提供免費修理及更換零件服務。經更換之任何損壞零件，將歸屬本公司。保修範圍不包括修理或更換損耗性零件如附件、外接線或機殼等；或除銹、髹漆、加工或清洗；或裝拆任何妨礙微波爐維修工作之裝修或設施，如需有關服務，用戶須另付費用。如不當使用本產品，或作(半)商業用途，或未依照使用說明書操作，維修保養將無效，本公司不會承擔任何損壞的維修及賠償。
2. 用戶必須於維修時出示購買／換購單據及蓋有銷售點／換購中心印章的產品保修記錄卡(必須登記並保存)，如有任何疑問，請致電信興電器服務中心有限公司熱線查詢：2406 5666。

Thank you for choosing Rasonic Grill Microwave Oven. Please read the operation manual carefully before using and keep this operation manual for your future reference.

Table of Contents

1. Installation Guideline
2. Important Safeguards for Usage
3. Utensil Precautions
4. Cleaning and Storage
5. Product Specifications
6. Product Identification
7. Operation Instructions
8. Special Avowal
9. After Sales Service

When using the appliance, please follow the safety precautions as below:

WARNING! Potential injury and product damage by misuse

1. Installation Guideline

To prevent fire, burn or electric shock, read the following instructions before in use

1. The appliance is a high power consumption electric appliance. Use an independent power source to supply. Do not connect with other high wattage appliance under the same socket, and make sure the input voltage match the rated voltage marked on the appliance.
2. The appliance must be earthed to avoid electric shock.
3. Net weight of the appliance is approximately 11 kg. Place the appliance on a horizontal rigid surface.
4. Place the appliance in a space with good ventilation. This microwave oven is freestand type, use it on table top and **DO NOT** place in a cabinet. Do not cover or block the air vents to avoid overheating, and do not place anything on the top of the appliance.
5. Allow at least 20cm clearance in between the top cover and the ceiling, at least 5cm on both sides to the wall and at least 10cm between back cover and the wall. The appliance and the ground should be at least 85cm apart. Make use of the distance spacer at the back of the appliance to limit the distance. Do not remove oven feet.
6. Do not place the appliance near poor heat-resistant materials such as plastic table cloth and cotton cloth, etc.
7. Place the appliance in a well-ventilated and dry place and keep it away from environment of corrosive gas, fire source, high temperature, steam, humid, oily or place where close to flammable materials.
8. Do not operate the appliance if the room temperature is too high.
9. The appliance shall be placed far away from TV, radio or antenna to prevent disturbance. Otherwise, noise may occur.

WARNING: If the door seals are damaged, the oven must not be operated until it has been repaired by a trained person.

2. Important Safeguards for Usage

2.1 Before first use

1. Remove all packing materials from the appliance. If there is protective film wrapping the appliance, remove it before using. (CAUTION: Do not remove the waveguide cover on the right hand side of oven cavity.)
2. Examine thoroughly if there is crack or damage on the appliance and accessories such as door safety lock, oven door and glass tray. Do not assembly or use it if any part is damaged.
3. Using grill function for the first times, it is normal phenomenon if smell or odor generated. As not to affect the cooking result, use grill function to heat up the appliance for 20 minutes and open the oven door for 10 minutes before placing the ingredients.
4. As there is protective oil remain inside the oven cavity, it usually would smell the odor, even a slight smoke, it is normal case and would not occur after using several times, keep the window open to ensure good ventilation.

2.2 To prevent the risk of fire in the oven cavity

1. Do not overcook the ingredients.
2. Remove all metallic seals or wire twists from the ingredients and packing. Electric arc generated on metallic surfaces may cause fire.
3. When heating food placed on plastic or paper containers, keep an eye on the oven due to possibility of ignition or burning as the materials are flammable.
4. Do not use the appliance to heat up oil or deep-fry as oil temperature may become uncontrollable.
5. To make popcorn, use special popcorn bags for microwave only.

6. Keep the oven cavity clean after each operation, especially the oven door, the contact surface between the cavity and door and the waveguide cover (Clean the waveguide cover by dry cloth only). Food residue and grease accumulated may deteriorate the material surface or cause dark smoke or fire. This could adversely affect the life cycle of the appliance and other hazard.
7. If there is smoke or fire during operation, keep the oven door closed in order to stifle any flames; otherwise, air will trigger the fire burning more intensely. Under safe situation, user should stop the operation and disconnect the main power supply immediately.

2.3 To prevent microwave leakage

To prevent harmful effects caused by microwave leakage, pay attention to the precautions below:

1. **WARNING!** Never tamper with the door safety lock system. If oven door cannot be closed firmly; or any deformation or damage found on the oven door or parts (e.g. hinge), stop operating the appliance immediately to avoid hazards. Contact Shun Hing Electric Service Centre Limited for repair before use.
2. Never place any foreign objects into the cavity during operation, especially metallic objects (e.g. fast food foil containers, etc).
3. Make sure to put the roller ring and glass tray to the oven cavity before operation.
4. Never use the microwave function without absorbing materials (such as food or water). These materials should be placed inside the cavity because reflection of microwave energy will affect the performance of the appliance. In case if the operation start accidentally without load, switch off the appliance immediately.
5. Do not heat chemicals or non-edible products. Do not clean the appliance by corrosive chemicals as heating up corrosive chemicals in the appliance may cause leakage of microwave radiation.
6. **WARNING!** It is hazardous for anyone other than an authorized person to carry out on service or repair the appliance that involves removal of any cover and waveguide cover which give protection against the exposure to microwave energy. Contact Shun Hing Electric Service Centre Limited if necessary.

2.4 Foods precautions

1. After heating baby food, always stir and check the temperature before serving. Ensure that heat is evenly distributed and the risk of scald or burns can be avoided.
2. Never use the appliance to heat hardboiled egg or eggs in their shell because pressure built up will lead to explosion. Stab the egg yolk and egg white by toothpick before heating. Besides, do not take out cooked dumpling and fried eggs right after heating. It may lead to explosion or liquid splashing from the food. Open the oven door and leave it for a moment before taking out.
3. Peel those food with sealed surface (e.g. eggs, chestnuts, potatoes, sausages which is skinned foods), or cut a few slides on the food skins by knife or pierce it by folk; otherwise, foods may expand and as a result of explosion.
4. Observe the food often when cooking small amount of food to avoid causing fire.
5. If wrapper is needed to cover the food, make sure it is compatible for microwave oven. Fold up a corner of the wrapper for proper ventilation. After cooking, remove the wrapper carefully to avoid scalding by steam.
6. Heating beverages can result in delayed eruptive boiling; great care must be taken when handling the container.
7. Factors that may affect cooking time are preferred degree of moisture content, starting temperature, altitude, volume, size, shape of food and utensil used. User can adjust the cooking time based on cooking experience.

2.5 Usage precautions

1. Do not use the cavity for storage. Do not leave paper products, cooking utensils or food in the cavity when the appliance is not in use.
2. Make use of the supplied glass tray and roller ring. To avoid accident, never replace them by any parts was produced without authorities, otherwise warranty becomes invalid.
3. Do not use recycled paper products, as they may contain impurities which may cause spark and fires when used.
4. Do not hit or strike control panel to avoid damage.
5. Do not cook food directly on glass tray unless indicated in the manual. (Food should be placed in a suitable cooking utensil beforehand.)
6. Make sure the utensils do not touch the interior walls during cooking, it must be placed at the centre of the glass tray; otherwise it may affect the rotation and cooking result.
7. Do not store flammable materials on top or in the cavity as it may cause fire.
8. Never rest objects on the door while it is open.
9. Check roasts and poultry temperature during cooking by temperature probe recommended for the oven. Do not use the conventional mercury thermometer in the appliance as it could cause fire or damage.
10. The appliance is not intended to be operated by means of an external timer or separate remote-control system.
11. Always use thick oven gloves when moving, flipping or removing food to avoid burns.
12. During operation or after use, the outer surface, oven cavity and accessible parts may be extremely hot. Do not touch to avoid burns. Children should be kept away from the appliance use it under adult supervision.
13. During operation, less steam may accumulate inside the cavity or on the oven door, condense water drops. This may occur when the microwave oven is operated under high humidity condition. This is a normal phenomenon, user can wipe with a soft dry cloth. The appliance is still in good working condition; steam will be evaporated when the appliance is cooled down.
14. When open the oven door, aware of the force and check whether the food inside is splashed out or upset to avoid danger, especially when cooking soup or beverages.
15. Do not use the appliance for purposes other than cooking. (The appliance may cause malfunction if user uses it other than cooking.)
16. The microwave oven is intended for heating food and beverages. Drying of food or clothing and heating of warming pads, therapeutic devices (e.g. wheat bags), slippers, sponges, damp cloth or newspaper may lead to risk of injury, ignition or fire.
17. To prevent damaging the glass tray, follow the safeguards as below:
 - a. Before cleaning the glass tray with water, let it cool down completely.
 - b. Do not put hot food or hot utensils on a cold glass tray.
 - c. Do not put cold food or cold utensils on a hot glass tray.
 - d. Do not exceed the maximum loading weight 4.5 kg of the glass tray.
18. Never immerse the appliance body, power cord and plug in water or let them wet, as to avoid functional damage and electric shock.
19. Great care is necessary when using the power cord. Do not place heavy objects on the power cord and clip the power cord. Any modification of the power cord is prohibited. Do not stretch or twist the power cord. Always hold the plug tightly with hands when unplugging or plugging in the socket.
20. After use or when not in use, make sure to unplug the appliance from the socket to prevent electric leakage and electric shock due to insulation degeneration. Do not touch, plug or unplug the appliance by wet hands which can result in electric shock.

21. Be sure to unplug the appliance and must wait it to cool down before moving, checking or cleaning.
22. The appliance is for household use only. Do not use it outdoors and in any other purpose or method which is not following the instructions in the user manual. If the appliance is used improperly, for commercial or semi-commercial use, your warranty becomes invalid and our company will refuse any liability and repairing cost for the damage caused.
23. Keep it out of reach for infants. Great care is necessary in using the appliance, especially near children. Make sure that they do not play with the appliance. Also, children without adult supervision should not operate the appliance do maintenance and keep them away from the appliance and its cord.
24. The appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, if they have given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
25. The appliance is intended to be used in household or similar environment such as staff kitchen areas in shops, offices and other working environments. Do not use it outdoors.
26. Always check the power cord, plug, oven door and door safety lock to ensure they are in good condition. In order to avoid hazards, stop operating the appliance immediately if any damaged or the appliance is dropped. In such case, please contact Shun Hing Electric Service Centre Limited for repair.
27. In order to comply with safety regulations and avoid hazards, repair of electrical appliances must be carried by authorized technicians. If the appliance needs to be repaired, please present the official invoice, warranty registration card with the appliance for repair service and contact Shun Hing Electric Service Centre Limited, hotline at 2406 5666. The address can be found in the back page of this manual.

3. Utensil Precautions

1. Utensil should be checked before use to ensure that it is suitable for microwave heating.
2. All metallic objects, utensils with metallic or silver rim should not be used for heating because it will cause sparking or over-heating. Damage the appliance may lead to fire or injury.
3. Avoid using containers which is straight-sided with narrow neck or sealed for cooking, as it may cause the container to explode.
4. To prevent fire, extreme care should be paid if foods are placed on disposable containers made by plastic, paper and other flammable materials.
5. Use wide-mouthed containers when heating liquids. If coffee powder, milk powder, cereal or other drink powder is added to the liquid, stir them thoroughly before heating. Let it cool down for few minutes after heating to prevent burns.
6. **WARNING:** Liquids or other foods (such as sealed glass or baby bottles etc.) must not be heated in sealed containers since they are liable to explode.
7. It is important to choose suitable cookware because the microwave energy must be able to penetrate the container to the food during cooking or defrosting. Round/oval dishes are preferable to square/oblong ones, as the food in the corners tends to overcook.

A variety of cookwares can be used as listed below. ("✓" Suitable, "X" Unsuitable)

Utensil	Combination Mode	Grilling	Microwave Cooking
Normal Plastic Utensils	X	X	X
Microwave-safe plastic wrap	X	X	✓
Grill Microwave-safe Glassware	✓	✓	✓
Grill Microwave-safe Ceramic Cookware	✓	✓	✓
Normal Glassware	X	X	X
Microwave-safe Plastic Utensil	X	X	✓
Aluminum Foil/Utensils	X	✓	X
Metal Rack	X	✓	X
Metal Utensil/Cookware	X	✓	X
Bamboo wood and Paper	X	X	X

4. Cleaning and Storage

1. Clean the food residues in the microwave oven regularly. The life cycle of the appliance may be adversely affected and possibly result in a hazardous situation if user cannot keep the appliance clean, leading waveguide to surface or other damages.
2. Always unplug the appliance and let it cool down completely before cleaning.
3. Do not clean the waveguide cover in the appliance cavity (located on the top right hand side) directly with water or damp cloth.
4. Always keep the inner, outer surface and oven window clean. Make use of mild detergent and a damp cloth or sponge to wipe during cleaning. Never scrape its surface with a hard brush to avoid damaging to the surface. (Attention: Do not allow water penetrating through gaps and air vents during cleaning.
5. Do not use harsh abrasive cleaners or sharp metal scrapers to clean the oven door glass since scrapers can scratch the surface resulting in shattering of the glass.
6. Steam cleaner is prohibited.
7. The glass tray and the roller ring should be cleaned regularly. Clean them by mild sudsy water, rinse with clean water and dry them afterward. Then put them back to the proper position.
8. If the control panel gets wet, clean with a soft and dry cloth. Do not use coarse and abrasive detergent and tool to clean the control panel. When cleaning the control panel, leave the door open to prevent the appliance from accidentally turning on.
9. Do not use poisonous or corrosive detergent to clean the appliance.
10. Allow the microwave oven to cool down completely and clean it before storage. Put it into the box and store in a dry place.
11. Never wrap the power cord tightly around the appliance or put any pressure on the power cord when storage as it could cause damage to the power cord.
12. Do not place any objects or allow dust or detergent residue accumulated in between the cover and the oven door.


5. Product Specifications

Model	RMO-W208MG	RMO-W209MG
Rated Voltage	220-240V~ 50Hz	
Rated Microwave Frequency	2450MHz	
Rated Input Power (Microwave)	1150W	
Rated Input Power (Grill)	700-800W	
Rated Output Power (Microwave)	700W	
Capacity	20L *	
Net Weight	10.1 kg (Approx.)	
Product Dimension (W x D x H)	451 x 344 x 258 mm (Approx.)	
Cavity Dimension (W x D x H)	302 x 296 x 192 mm (Approx.) [#]	

* Manufacturer's Standard


[#] Internal capacity is calculated by measuring the maximum width, depth and height of the cavity. Actual capacity for cooking food is less than the above value.

6. Product Identification



1	Door Safety Lock System	The appliance can operate only when the door is closed. Opening the door during cooking will stop the cooking process without cancelling the program.
2	Oven Window	Check the food condition through the window.
3	Rotating Axis	The place where the glass tray sits on; the motor underneath drives the glass tray to rotate.
4	Roller Ring	Place it in the middle of the cavity then place the glass tray on to the ring so that it locates firmly into the axis.
5	Glass Tray	Containers with food loaded will be placed on it. During operation, the food will rotate such that it can be evenly cooked.
6	Control Panel	Refer to Chapter 6.1 Control Panel Guide .
7	Waveguide cover (DO NOT REMOVE)	Situated at the right of the cavity, protecting the microwave hole and preventing obstruction caused by spraying due to the moisture in the food.
8	Rack	Food can be placed either directly onto the rack, or on the dish/ heat-resistant plate. (Not applicable to combination and microwave heating)
9	Distance Spacer	Ensure sufficient ventilation from the back wall.

6.1 Control Panel Guide



Control Panel

Turn the [Power] knob to select cooking function. There are 9 modes for selection.

Microwave function

5 power levels of microwave are available. Power level increases by turning the [Power] knob clockwise.

The power levels can be set as follow:

	Microwave Level	Power	Suggested Application [#]
1	Low	18%	Keep Warm
2	Defrost*/ M.Low	36%	Defrost
3	MED	58%	Stewing
4	M.HIGH	81%	Roasting
5	HIGH	100%	Express Cooking

Grill function

CAUTION: As the steel plate of microwave oven is coated with lubricating oil, smoke and odor will be generated because of eliminating the remaining lubricating oil for the first use of grill function. It is a normal phenomenon.

Grill cooking function is particularly useful for thin slices of meat, such as steaks, pork chops, sausages or chicken wing, etc. It is also suitable for toasting sandwiches and making surface of food crispy.

*Defrost function

The following table provides reference defrosting time for various foods.

Ingredient Type	Weight Range (kg)	Suggested Defrost Time (min: sec.) [#]
Meat	0.1-1	1:30-26:00
Poultry	0.2-1	2:30-22:00
Seafood	0.1-0.9	1:30-14:00

Cooking Combination

Cooking combination power levels can be classified as follow:

Combination	Microwave Time	Grill Time	Suggested Ingredient [#]
COMBI.1	30%	70%	Steak
COMBI.2	49%	51%	Meat & chick
COMBI.3	67%	33%	Poultry

[#] The suggested application and time are for reference only, user may adjust the desired setting depending on their personal preference.

WARNING! When the appliance is operated in grill or combination mode, children should only use the oven under adult supervision due to the temperature generated.

Heating time setting

1. Turn the [Time] knob to adjust the heating time.
2. Available heating time is from 1 minute to 30 minutes.

7. Operation Instructions

1. Before connecting the power cord, make sure the [Time] knob is set to "0" (OFF) position. Do not block the ventilation when using.
2. Prepare and place food in a suitable container (refer to **Chapter 3. Utensil Precautions**), put them directly onto the middle of the glass tray then close the door.
3. Turn the [Power] knob to the desired cooking function.
4. Turn the [Time] knob to the desired cooking time. The oven lamp will light up and the oven will start automatically.
5. When the operation complete, the [Time] knob will return to "0" (OFF) and the signal will sound. The oven lamp will turn off automatically and the glass tray stops rotating.
6. Open the oven door, take out the food/container carefully. Leave it for a while as required.

Safety Hints

1. If you wish to stop the operation before the cooking time set, turn the [Time] knob back to "0" (OFF) position.
2. If you wish to change the cooking time during cooking, simply turn the [Time] knob to the desired setting. If you want to adjust the heating power or change the function, turn the [Power] knob to desired setting directly.
3. When cooking is less than 3 minutes, turn the [Time] knob to 10 minutes mark first. Then turn back to the desired setting as a result of more accurate setting.

CAUTION! Ensure the [Time] knob is returned to "0" (OFF) position at the end of the operation; otherwise, the oven will start automatically when the oven door is closed again.

8. Special Avowal

1. The content in the operation manual has been checked. Our company reserves the hermeneutic power to any printing errors or misunderstanding on the content.
2. If there are technical improvements on the appliance, the operation manual will be updated in new version without prior notice. The product appearance and specification are subject to the manufacturer information.
3. In case there is any inconsistency or conflict between the English versions and Chinese versions of the terms, the Chinese versions shall prevail.
4. E-copy of user manual can be sent by e-mail on request, please call Shun Hing Electric Works & Engineering Co., Ltd. at 2861 2767.

9. After Sales Service

1. For any defect, in the judgment of technician from Shun Hing Electric Service Centre Limited, caused under normal use, our company is responsible for repairing and replacing any parts of the said electrical appliance free of charge within one year guarantee period commencing from the date of purchase. Any defective part which has been replaced shall become our property. Warranty service does not cover the repair or replacement of consumable parts such as accessories, external cables or cabinet, etc; or rust-removal, painting, decoration or cleaning of the microwave oven; or removal and reinstatement of any decorations or facilities hindering the service work of the microwave oven. Additional charges shall be levied if such services are required. If the appliance is used improperly, for commercial or semi-commercial use, or not following the instructions in the operation manual, the warranty becomes invalid and our company will refuse any liability and repairing cost for the damage caused.
2. User must present the official invoice/redemption voucher and the product warranty card (Shall be registered and keep it well) with the chop from sales point/redemption center for maintenance. For enquiries, please call Shun Hing Electric Service Centre Limited hotline at 2406 5666.



信興電工工程有限公司

SHUN HING ELECTRIC WORKS AND ENGINEERING CO., LTD.

辦公室：香港九龍尖沙咀東部麼地道67號半島中心9樓

電話：2861 2767

圖文傳真：2865 6706

網址：<http://www.rasonic.com>

電郵：shew@shunhinggroup.com

Office: 9/F, Peninsula Centre 67 Mody Road, Tsimshatsui East Kowloon Hong Kong

Tel: 2861 2767

Fax: 2865 6706

Website: <http://www.rasonic.com>

E-mail: shew@shunhinggroup.com

保養及維修 Maintenance and Repair Service:

信興電器服務中心有限公司

SHUN HING ELECTRIC SERVICE CENTRE LTD.

香港新界葵涌勝耀街2號信興中心11樓

服務熱線：2406 5666

傳真號碼：2408 0316

網址：<http://www.shesc.com/zh>

11/F, Shun Hing Centre, 2 Shing Yiu Street, Kwai Chung, N.T. H.K.

Service Hotline: 2406 5666

Fax No.: 2408 0316

Website: <http://www.shesc.com/en>

客戶服務中心：

香港新界葵涌勝耀街2號信興中心1樓

九龍尖沙咀東部麼地道67號半島中心B座9樓

香港天后琉璃街7號柏景中心22樓

澳門慕拉士大馬路193-199號南嶺工業大廈5樓1座

Customer Service Centres:

1/F, Shun Hing Centre, 2 Shing Yiu Street, Kwai Chung, N.T.

9/F, Block B, Peninsula Centre, 67 Mody Road, Tsim Sha Tsui East, Kowloon

22/F, Parkview Centre, 7 Lau Li Street, Tin Hau, Hong Kong

Avenida de Venceslau de Morais, No. 193-199, 5 andar-l, Edif. Industrial Nam Leng, Macau

有關最新之香港及澳門客戶服務中心資料，請參閱信興服務中心網址：<http://www.shesc.com/zh>。

For the latest information of Hong Kong and Macau service center, please visit <http://www.shesc.com/en>.