

1 SELECT THE BEST LOCATION (Refer to "Select the best location" section)

2 HOW TO FIX INSTALLATION PLATE

The mounting wall shall be strong and solid enough to prevent it from vibration.

Model	①	②	③	④	⑤	⑥	⑦	⑧
2.0HP	587 mm	70 mm (+)	537 mm	503 mm	176 mm	228 mm	276 mm	210 mm

- The center of installation plate should be at more than ① at right and left of the wall.
 - The distance from installation plate edge to ceiling should be more than ②.
 - From installation plate center to unit's left side is ③.
 - From installation plate center to unit's right side is ④.
 - For left side piping, piping connection for liquid should be about ⑤ from this line.
 - For left side piping, piping connection for gas should be about ⑥ from this line.
- Mount the installation plate on the wall with 5 screws or more (at least 5 screws). (If mounting the unit on the concrete wall, consider using anchor bolts.)
 - Always mount the installation plate horizontally by aligning the marking-off line with the thread and using a level gauge.
 - Drill the piping plate hole with $\phi 70$ mm hole-core drill.
 - Line according to the left and right side of the installation plate. The meeting point of the extended line is the center of the hole. Another method is by putting measuring tape at position as shown in the diagram above. The hole center is obtained by measuring the distance namely 210 mm for left hole and 150 mm for right hole (2.0 - 2.5HP).
 - Drill the piping hole at either the right or the left and the hole should be slightly slanting to the outdoor side.

3 TO DRILL A HOLE IN THE WALL AND INSTALL A SLEEVE OF PIPING

- Insert the piping sleeve to the hole.
- Fix the bushing to the sleeve.
- Cut the sleeve until it extrudes about 15 mm from the wall.
- Finish by sealing the sleeve with putty or caulking compound at the final stage.

CAUTION

When the wall is hollow, please be sure to use the sleeve for tube assembly to prevent dangers caused by mice biting the connection cable.

1 SELECT THE BEST LOCATION (Refer to "Select the best location" section)

2 INSTALL THE OUTDOOR UNIT

- After selecting the best location, start installation according to Indoor/Outdoor Unit Installation Diagram.
- Please mount the outdoor unit on stable ground to prevent vibration and increase of noise level.
- Decide the location for piping after sorting out the different types of pipe available.
- Fix the unit on concrete or rigid frame firmly and horizontally by bolt nut ($\phi 8$ mm).
- When installing at roof, please consider strong wind and earthquake.

CONDENSED WATER DISPOSAL OF OUTDOOR UNIT

Please fasten the installation stand firmly with bolt or nails.

- There is hole on the base of outdoor unit for condensed water to exhaust.
- When connecting the drain hose, it must be below the horizontal line and the drain hose keep smooth, in order to flow condensed water to the drain elbow.

CAUTION

Install the outdoor unit horizontally or keep the air outlet side higher than the horizontal plane 0 ~ 2" and make sure that condensate drains away.

3 CONNECTING THE PIPING

Connecting Piping to Indoor

For connection joint of all models
Please make flare after inserting flare nut (locate at joint portion of tube assembly) onto the copper pipe. (In case of using long piping)
Connect the piping

- Align the center of piping and sufficiently tighten the flare nut with fingers.
- Further tighten the flare nut with torque wrench in specified torque as stated in the table.

Additional Precautions For R32 Models when connecting by flaring at indoor side

Ensure to do re-flaring of pipes before connecting to units to avoid leaking

Seal sufficiently the flare nut (both gas and liquid sides) with neutral cure (Alkoxy type) and ammonia-free silicone sealant and insulation material to avoid the gas leak caused by freezing.

Neutral cure (Alkoxy type) and ammonia-free silicone sealant is only to be applied after pressure testing and clearing up by following instructions of sealant, only to the outside of the connection. The aim is to prevent moisture from entering the connection joint and possible occurrence of freezing. Curing sealant will take some time. Make sure sealant will not peel off when wrapping the insulation.

Apply neutral cure (Alkoxy type) and ammonia-free silicone sealant along the circumference

Do not overtighten, overtightening may cause gas leakage.

Piping size	Torque
6.35 mm (1/4")	118 N·m (1.8 kgf·m)
9.52 mm (3/8")	142 N·m (4.3 kgf·m)
12.7 mm (1/2")	155 N·m (5.8 kgf·m)
15.88 mm (5/8")	165 N·m (6.6 kgf·m)
19.05 mm (3/4")	100 N·m (10.2 kgf·m)

CUTTING AND FLARING THE PIPING

- Please cut using pipe cutter and then remove the burrs.
- Remove the burrs by using reamer. If burrs is not removed, gas leakage may be caused. Turn the piping end down to avoid the metal powder entering the pipe.
- Please make flare after inserting the flare nut onto the copper pipes.

Do not overtighten, overtightening may cause gas leakage.

When properly flared, the internal surface of the flare will evenly shine and be of even thickness. Since the flare part comes into contact with the connections, carefully check the flare finish.

4 INDOOR UNIT INSTALLATION

- FOR THE RIGHT REAR PIPING
 - Pull out the Indoor piping
 - Install the Indoor Unit
 - Secure the Indoor Unit
 - Insert the connection cable
- FOR THE RIGHT AND RIGHT BOTTOM PIPING
 - Pull out the Indoor piping
 - Install the Indoor Unit
 - Insert the connection cable
 - Secure the Indoor Unit

CAUTION

Do not turn over the unit without shock absorber during pull out the piping. It may cause intake grille damage.

Use shock absorber during pull out the piping to protect the intake grille from damage.

Pull out the Indoor piping

Right Rear piping

Right piping

How to keep the cover

Install the indoor unit

Secure the Indoor Unit

Power supply cord arrangement

Insert the connection cable

To take out the unit, push the ∇ marking at the bottom unit, and pull it slightly towards you to disengage the hooks from the unit.

AIR PURGING METHOD IS PROHIBITED FOR R32 SYSTEM

4 AIR TIGHTNESS TEST ON THE REFRIGERATING SYSTEM

Do not purge the air with refrigerants but use a vacuum pump to vacuum the installation.

There is no extra refrigerant in the outdoor unit for air purging.

- Before system is charged with refrigerant and before the refrigerating system is put into operation, below site test procedure and acceptance criteria shall be verified by the certified technicians, and/or the installer.
- Be sure to check whole system for gas leakage.

Preparation (Step 1-2)

Evacuation (Step 3-4)

Tightness Test with Inert Gas (Step 5-7)

Pressure drop? (Step 8)

Recovery of Test Gas (Step 13)

Evacuation (Step 3-4)

Open 2 and 3 valves (Step 14-18)

Complete

- Connect a charging hose with a push pin to the Low side of a charging set and the service port of the 3-way valve. During extremely cold winter, material contraction might happened, try to further tighten the 2-way, 3-way valve to ensure they are fully closed.
- Attach the gauge manifold set correctly and tightly. Make sure that both valves of the manifold gauge (low pressure and high pressure) is in close position.
- Connect the center hose of the manifold gauge to a vacuum pump.
- Turn on the power switch of the vacuum pump, then turn open the low side manifold gauge valve and make sure that the needle in the gauge moves from 0cmHg (0 MPa) to -76 cmHg (-0.1 MPa) or vacuum until 500 microns is achieved. This process continues for approximately ten minutes. Then close the low side manifold gauge valve.
- Remove the vacuum pump from the centre hose and connect the center hose to cylinder of any applicable inert gas as test gas.
- Charge test gas into the system and wait until the pressure within the system to reach min. 1.04MPa (10.4bar).
- Wait and monitor the pressure reading on the gauges. Check if there is any pressure drop. Waiting time depends on the size of the system.
- If there is any pressure drop, perform step 9-12. If there is no pressure drop, perform step 13.
- Use Gas Leak Detector to check for leaks. Must use the detection equipment with a sensitivity of 5 grams per year of test gas or better.
- Move the probe along the air conditioning system to check for leaks, and mark for repair.
- Any leak detected and marked shall be repaired.
- After repair, repeat evacuation steps 3-4 and tightness test steps 5-7. Check the pressure drop as in step 8.
- If no leak, Recover the test gas. Perform evacuation of steps 3-4. Then proceed to step 14.
- Disconnect the charging hose from the service port of the 3-way valve.
- Tighten the service port caps of the 3-way valve at a torque of 16 Nm with a torque wrench.
- Remove the valve caps of both of the 2-way valve and 3-way valve.
- Open both of the valves, using a hexagonal wrench (4 mm).
- It is recommended to allow refrigerant slowly flow into the refrigerant system to prevent refrigerant freezing. Slightly open 2-way valve for 5 seconds then close the valve. Repeat this action for 3 cycles then fully open the valve.
- Mount back the valve caps onto the 2-way valve and the 3-way valve to complete this process.

Notes: Recommended use of any of the following leak detector,
I) Universal Sniffer leak detector
II) Electronic halogen leak detector
III) Ultrasonic Leak Detector

3. FOR THE EMBEDDED PIPING

- Change the drain hose position
- Bend the embedded piping
- Pull the connection cable into Indoor Unit
- Cut and flare the embedded piping
- Install the Indoor Unit
- Connect the piping
- Insulate and finish the piping
- Secure the Indoor Unit

(This can be used for left rear piping also.)

Fasten the chassis to the installation plate with screws (Self purchase. Screw size: M4, max. length 10 mm) to provide a neat appearance of indoor unit.

Connect the cable to the indoor unit

The indoor and outdoor unit connection cable can be connected without removing the front grille.

- Install the indoor unit on the installing holder that mounted on the wall.
- Open the front panel and grille door by loosening the screw.
- Connection cable between indoor unit and outdoor unit shall be approved polychloroprene sheathed. 4 x 1.5 mm² flexible cord, type designation 60245 IEC 57 or heavier cord. Do not use joint connection cable. Replace the wire if the existing wire (from concealed wiring, or otherwise) is too short.
- Bind all the indoor and outdoor Connection cable with tape and route the connection cable via the right side escapement.

Check the drainage

Remove the tapes and connect the connection cable between indoor unit and outdoor unit according to the diagram below.

Secure firmly the connecting cable onto the control board with the holder. Do not overtighten holder screw, as this may damage the holder.

Close grille door by tighten with screw and close the front panel.

Note:

- Isolating Devices (Disconnecting means) should have minimum 3.0 mm contact gap.
- Ensure the colour of wires of outdoor unit and the terminal Nos. are the same to the indoor's respectively.
- Earth wire shall be Yellow/Green (Y/G) in colour and longer than other AC wires as shown in the figure for the electrical safety in case of the slipping out of the cord from the anchorage.

WIRE STRIPPING, CONNECTING REQUIREMENT

Wire stripping

No loose strand when inserted

Indoor/outdoor connection terminal board

5 mm or more (gap between wires)

Conductor fully inserted

Conductor over inserted

Conductor not fully inserted

ACCEPT PROHIBITED PROHIBITED

RISK OF FIRE

JOINING OF WIRES MAY CAUSE OVERHEATING AND FIRE.

Do not joint wires

Use complete wire without joining.

Use approved socket and plug with earth pin.

Wire connection in this area must follow to national wiring rules.

5 CONNECT THE CABLE TO THE OUTDOOR UNIT

- Remove the control board cover from the unit by loosening the screws.
- Connection cable between indoor unit and outdoor unit shall be approved polychloroprene sheathed 4 x 1.5 mm² flexible cord, type designation 60245 IEC 57 or heavier cord. Do not use joint connection cable. Replace the wire if the existing wire (from concealed wiring, or otherwise) is too short.
- Secure the cable onto the control board with the holder (clammer).
- Attach the control board cover to the original position with the screws.
- For wire stripping and connection requirement, refer to instruction ⑤ of indoor unit.
- Earth wire shall be Yellow/ Green (Y/G) in color and longer than other AC wires for safety reason.

Check the drainage

Remove the tapes and connect the connection cable between indoor unit and outdoor unit according to the diagram below.

Secure firmly the connecting cable onto the control board with the holder. Do not overtighten holder screw, as this may damage the holder.

Close grille door by tighten with screw and close the front panel.

Note:

- Isolating Devices (Disconnecting means) should have minimum 3.0 mm contact gap.
- Ensure the colour of wires of outdoor unit and the terminal Nos. are the same to the indoor's respectively.
- Earth wire shall be Yellow/Green (Y/G) in colour and longer than other AC wires as shown in the figure for the electrical safety in case of the slipping out of the cord from the anchorage.

WIRE STRIPPING, CONNECTING REQUIREMENT

Wire stripping

No loose strand when inserted

Indoor/outdoor connection terminal board

5 mm or more (gap between wires)

Conductor fully inserted

Conductor over inserted

Conductor not fully inserted

ACCEPT PROHIBITED PROHIBITED

RISK OF FIRE

JOINING OF WIRES MAY CAUSE OVERHEATING AND FIRE.

Do not joint wires

Use complete wire without joining.

Use approved socket and plug with earth pin.

Wire connection in this area must follow to national wiring rules.

6 PIPING INSULATION

- Please carry out insulation at pipe connection portion as mentioned in Indoor/Outdoor Unit Installation Diagram. Please wrap the insulated piping and to prevent water from going inside the piping.
- If drain hose or connecting piping is in the room (where dew may form), please increase the insulation by using POLY-E FOAM with thickness 6 mm or above.

HOW TO TAKE OUT FRONT GRILLE

Please follow the steps below to take out front grille if necessary such as when installing or servicing.

- Set the vertical vane airflow direction louvers to the horizontal position.
- Slide the 4 caps on the front grille as shown in the illustration.
- Open front panel.
- Remove the 6 screws on the front grille as shown in the illustration.
- Slide the 4 knobs on the upside of front grille to unlock position.
- Pull the front grille towards you to remove the front grille.

When reinstalling the front grille, carry out above steps in the reverse order.

AUTO SWITCH OPERATION

The below operations will be performed by pressing the "AUTO" switch.

- AUTO OPERATION MODE
The Auto operation will be activated immediately once the Auto Switch is pressed and release within 5 sec.
- TEST RUN OPERATION (FOR PUMP DOWN/SERVICING PURPOSE)
The Test Run operation will be activated if the Auto Switch is pressed continuously for more than 5 sec. to below 8 sec. A "pep" sound will occur at the fifth sec., in order to identify the starting of Test Run operation.
- REMOTE CONTROLLER RECEIVING SOUND ON/OFF
The ON/OFF of Remote controller receiving sound can be change over by the following steps:
a) Press "AUTO" switch continuously for more than 16 sec. to below 21 sec. A "pep", "pep", "pep", "pep" sound will occur at the sixteen sec.
b) Press the "AC Reset" button once, "pep" sound will occur indicates that Remote controller receiving sound setting mode is activated.
c) Press "AUTO" switch again. Everytime "AUTO" switch is pressed (within 60 sec. interval), Remote controller receiving sound status will be reversed between ON and OFF. Long "pep" sound indicates that Remote controller receiving sound is ON. Short "pep" sound indicates that Remote controller receiving sound is OFF.

EVALUATION OF THE PERFORMANCE

- Operate the unit at cooling/heating operation mode for fifteen minutes or more.
- Measure the temperature of the intake and discharge air.
- Ensure the difference between the intake temperature and the discharge is more than 8 °C during Cooling operation or more than 14 °C during Heating operation.

Note:

- During winter, turn on the power supply and standby the unit for at least 15 minutes before test run. Allow sufficient time to warm up refrigerant and prevent wrong error code judgement.

IN CASE OF REUSING EXISTING REFRIGERANT PIPING

Observe the followings to decide reusing the existing refrigerant piping.

Poor refrigerant piping could result in product failure.

- In the circumstances listed below, do not reuse any refrigerant piping. Instead, make sure to install a new piping.
 - Heat insulation is not provided for either liquid-side or gas-side piping or both.
 - The existing refrigerant pipe has been left in an open condition.
 - The diameter and thickness of the existing refrigerant piping does not meet the requirement.
 - The piping length and elevation does not meet the requirement.
- Perform proper pump down before reuse piping.
- In the circumstances listed below, clean it thoroughly before reuse.
 - Pump down operation cannot be performed for the existing air-conditioner.
 - The compressor has a failure history.
 - Oil color is darken. (ASTM 4.0 and above).
 - The existing air-conditioner is gas/oil heat pump type.
- Do not reuse the flare to prevent gas leak. Make sure to install a new flare.
- If there is a welded part on the existing refrigerant piping, conduct a gas leak check on the welded part.
- Replace deteriorated heat insulating material with a new one. Heat insulating material is required for both liquid-side and gas-side piping.

Proper Pump Down Method

- Operate air conditioner at cooling mode for 10 ~ 15 minutes.
- After 10 ~ 15 minutes of pre operation, close 2 way valve. After 3 minutes, close 3 way valve.
- Take out air conditioner unit.
- Install New Refrigerant air conditioner.

Most Important Process Purpose: To make the oil & refrigerant mix together. They are in separated condition when air conditioner is stopped.

Mixed refrigerant & oil will be collected into outdoor unit.

Only very small amount of oil remain inside piping, which is acceptable.

CHECK ITEMS

<input type="checkbox"/> Is there any gas leakage at flare nut connections? <input type="checkbox"/> Has the heat insulation been carried out at flare nut connection? <input type="checkbox"/> Is the connection cable being fixed to terminal board firmly? <input type="checkbox"/> Is the connection cable being clamped firmly? <input type="checkbox"/> Is the drainage ok? <input type="checkbox"/> (Refer to "Check the drainage" section) <input type="checkbox"/> Is the earth wire connection properly done?	<input type="checkbox"/> Is the indoor unit properly hooked to the installation plate? <input type="checkbox"/> Is the power supply voltage complied with rated value? <input type="checkbox"/> Is there any abnormal sound? <input type="checkbox"/> Is the cooling/heating operation normal? <input type="checkbox"/> Is the thermostat operation normal? <input type="checkbox"/> Is the remote control's LCD operation normal?
---	---

ENGLISH

ACXF60-49270

PRINTED IN MALAYSIA